



Adjusting Rear Arm Hole Shot Device

1. Collapse the rear idler arm by applying pressure to the back of the snowmobile.
 2. When the arm is pivoted towards the rear, rotate the cam arm to the desired position.
 3. While holding the device in its desired position, relieve the pressure off the snowmobile to secure cam at desired position.
- NOTE: Of the two positions, Position 1 applies the least amount of track on the ground, where Position 2 applies the most.
 - NOTE: The installed spring allows the cam arm to return to its original position as soon as the rear arm is compressed past the point it was set at.

About Arctic Cat

The Arctic Cat brand is among the most widely recognized and respected in the recreational vehicle industry. The company designs, engineers, manufactures and markets all-terrain vehicles (ATVs), side-by-sides and snowmobiles, in addition to related parts, garments and accessories under the Arctic Cat® and Motorfist® brand names. Arctic Cat Inc.'s world headquarters is located in Minneapolis, Minnesota. Its common stock is traded on the NASDAQ Global Select Market under the ticker symbol "ACAT." More information about Arctic Cat and its products is available at www.arcticcat.com.